

EasyView

Getting started

Version 4.4

Installation

Installing EasyView

Any present version of EasyView must be **uninstalled** before installing a new version. Select *Start -> Programs -> Ernitec -> EasyView -> Uninstall EasyView*.

Insert the EasyView labeled CD-ROM into your CD drive. If auto run is enabled, the installation program will start automatically.

Alternatively, select *Start -> Run*, and type D:\Setup.exe (D, being your CD-ROM drive)

The EasyView installation menu will appear. Click *Next* and follow the on-screen instructions to install EasyView.

Hardware Security Dongle

After installation of EasyView, plug the included **USB Dongle** into a free USB Port. The Dongle is a copy protection, and is required for full EasyView functionality. The number of cameras available is defined by the dongle.

If the **Found New Hardware Wizard** pops up, select the option: *Yes, this time only* and click *Next*.

On the next page select the option: *Install the software automatically*.

If the Dongle driver is not found automatically, specify the file path \Ernitec\EasyView\Drivers\IWUSB.SYS if the "Program Files" directory manually.

If started without a dongle, EasyView will start in **Demo Mode** which has limited functionality.

Getting started


Select *Start -> Programs -> Ernitec -> EasyView -> EasyView*

F1 Help

Press [F1] key to get context sensitive help throughout EasyView.

Log On

At EasyView startup you will be presented to a Log On dialog.
Enter the default User Name: *EasyView* and the Password: ******.



You are now in **Design Mode** (blue background) where it is possible to configure EasyView.
Start by adding a user with administrator rights.

Add users

Select the menu *Wizard -> Users*. It opens the EasyView user dialog.
Add at least one user with **Administrator** rights.

Save configuration file

Select the menu *File -> Save As* and save the EasyView configuration under a given name.

Configuration

The EasyView configuration can hold a large number of components used for video surveillance:

- Devices/Units
- Analogue and IP cameras
- Inputs/Outputs
- Alarm handling
- Macro handling
- Site map/floor plan
- Analogue monitors

In the following some of the most common EasyView configurations will be explained in more details. You can skip the sections not applicable for your environment.

DVR Configuration

Select the menu *Wizard -> DVR*. It opens the DVR wizard.

The DVR wizard is used to add, remove and modify DVR units, cameras, inputs and outputs to the EasyView configuration.

Press **[F1]** key to get context sensitive help throughout the DVR wizard.

- Sites
Add a site for each place where you have the DVR's. A site groups one or several DVR's and the attached cameras.
- DVR's
Select a site from the drop-list. Add the DVR's connected to this site. Configure the DVR's with name, IP address etc.
Select another site and add the DVR's connected to this other site etc.
- Cameras
Select a DVR from the drop-list.
Please note that only the DVR's from the previous selected site are displayed. To configure DVR's from other sites, click the Back button until you can select another site.
Add and configure each camera with name, ID and camera type (FIX, PTZ)
- Inputs
Select a DVR from the drop-list.
Add and configure each input with name and ID
- Outputs
Select a DVR from the drop-list.
Add and configure each output with name and ID.

NVR Configuration

Select the menu *Wizard -> NVR Camera Import*. It opens the NVR wizard.

The NVR wizard is used to add, remove and modify NVR units and cameras to the EasyView configuration.

Press **[F1]** key to get context sensitive help throughout the NVR Camera Import wizard.

- NVR's
Add and configure the NVR's with name, server type, IP address, user name and

password.

- Select a NVR from the drop-list and click Next to import the cameras from the NVR.
- Check the cameras that shall be imported. Configure the PTZ cameras with correct type and ID.

System-X Configuration

Select the menu *Wizard -> SystemX import*. It opens the System-X wizard.

The System-X wizard is used to add, remove and update System-X units and cameras to the EasyView configuration.

Press [F1] key to get context sensitive help throughout the SystemX import wizard.

- NodeManager export file
Browse and select the previously made Node Manager export file.
- Enable the I151SX-PCIF devices that shall be imported and configure the COM port for each device.
- Save the configuration to an EasyView configuration file (normally placed under C:\Ernitec\EasyView\Databases\)

Advanced Setup

Select the menu *View -> Advanced Setup*. It opens the Advanced Setup dialog.

The Advanced Setup dialog is used to add, remove and modify devices, cameras, inputs, outputs and analogue monitors in the EasyView configuration. This dialog is for EasyView experts and requires some prior EasyView experience.


However this dialog may be the only way to handle certain devices not handled by the wizards.

- Connections
Use this tab to add, delete or modify devices. The driver must be selected from the drop-list and it must be configured.
- Cameras
Use this tab to add, delete or modify cameras. A camera must be placed under a location. Under the camera-connection tab, right-click the device the camera is associated with. Under the camera-camera type tab, configure the camera.
- Input
Use this tab to add, delete or modify inputs. An input must be placed under a location. Under the input-connection tab, right-click the device the input is associated with. Under the input-input config tab, configure the input.
- Output
Use this tab to add, delete or modify outputs. An output must be placed under a location. Under the output-connection tab, right-click the device the output is associated with. Under the output-output config tab, configure the output.
- Monitors
Use this tab to add, delete or modify analogue monitors. An analogue monitor must be placed under a location. Under the monitor-connection tab, right-click the device the analogue monitor is associated with. Under the monitor-monitor config tab, configure the analogue monitor.

Layout

Select the menu *Layout* -> *Show*. You will now leave Design Mode and enter **Layout Mode** (green background).

The layout mode defines the windows you want on the screen and where. Layout mode **does not**, like design mode, define the EasyView configuration/contents of the windows, only the layout.


Close all windows (click on the icon ). Under the menu *View* you can select the windows you want. Select at least the windows:

- Splitscreen
- Camera List

Press [**F1**] key to get more context sensitive help.

Select the menu *Layout* -> *Hide* to leave Layout mode and enter Design Mode once again.

Operation mode

Click on the icon  in the bottom panel. You will now leave Design Mode and enter **Operational Mode**.

In operational mode you can see the camera video streams by drag/dropping the cameras from the camera list to the Split Screen.

Press **[F1]** key to get more context sensitive help.

Technical specifications

Compatibility

EasyView is compatible with the following equipment:

- DigiOp DVR's
- EDNS 2000 DVR
- Ernitec IP camera
- IP Ernitec NVR Basic
- IP Ernitec NVR Standard
- Ernitec Video Encoder
- System-X IP
- System-X RS232 (I151SX-PCIF)
- VB8000 Video Server
- W&T WEB-IO

Computer/Network Requirements

These are the Computer/Network requirements for the EasyView program.

- Intel Pentium 4 3.0 GHz
- Windows 2000/XP Operating System
- Graphic card 128 MB RAM
- PC Monitor capable of resolution 1280x1024
- 1024 MB RAM, 2048 MB RAM recommended
- 200 MB free Hard Disk space (depends on installation type)
- CD ROM Drive
- Free USB Port
- Windows compatible Pointing Device (Mouse)
- 100 Mbits/s Ethernet IP Network

Trademarks

Echelon, LON and LONWORKS are trademarks of Echelon Corporation registered in the United States and other countries.

All other brand and product names are trademarks of their respective companies.

Advanced setup.

In advanced setup the entire EasyView database is available for configuration.

The configuration parts are divided into:

- λ [Connections](#), to the devices
- λ [Cameras](#)
- λ [Inputs](#)
- λ [Outputs](#)
- λ [Monitors](#)
- λ [Alarms](#)

Advanced setup of Connections

A connection represents a physical connection between EasyView and a device.


A device may be a IP camera or a DVR/ NVR with a number of cameras connected to this device. Furthermore a device may be a bridge to another network topology, such as IP to LonWorks for the SystemX.

The screenshot displays the EasyView software interface for configuring a connection. On the left, a tree view lists several connection types: EDNS2000, EDNS4000, EDNS5000, EDNS6000, Ernitec NVR, NVR 1, VCX, and WEB-IO. The 'VCX' option is selected. The main configuration area is titled 'Driver for System-X IP' and contains the following fields:

- Driver:** A dropdown menu set to 'System-X IP'.
- Enable Connection:** An unchecked checkbox.
- Can be used as stream:** An unchecked checkbox.
- Monitor:** A dropdown menu set to '1'.
- Address:** A text input field containing '192.168.6.121'.
- User Name:** A text input field containing 'Admin'.
- Password:** A text input field containing '123456'.


At the bottom of the window, there is a toolbar with icons for '+', '-', 'Connections', 'Cameras', 'Inputs', 'Outputs', 'Monitors', and a red alarm icon. The 'Connections' icon is currently active.

A connection utilize an instance of a given driver type to make the interface between EasyView and the device.

Use the  button to add a new connection. Select the type of driver to be used.

Enable the connection, and select the "Can be used as stream".


Enter the address, either the IP address or host name, for the device, and type the user name and password for a account on the device.


Use the  button to remove a connection.


Advanced setup of Cameras

A camera represents a physical camera or a video input channel on a DVR/ NVR.


Add/ remove cameras:



Use the  button to add a new location/ site to the configuration of cameras.



Use the button to add a new camera to the location/ site.



Use the button to remove a camera from a location/ site.



Use the button to remove a location/ site and all the cameras within it.

A [connection](#) must be assigned to the camera, and the camera must belong to a location/ site



Use the button to expand the collection tree view or the button to collapse the collection tree view.

Select the connection from the tree view by right-click on the item

Location/ site Type:

Default site number is 1, and default size is 1024.

If EasyView is connected to SystemX the site number uniquely identifies the site, and the devices on the site.

The site size is used when EasyView is connected to SystemX, and the total number of sites must be increased, and thus the number of devices per sites must be decreased.

Connection	Camera type
Site	<input type="text" value="1"/>
Site size	<input type="text" value="1024"/>

Cameras Type:

The camera type have different attributes, such as Fix or PTZ, a control ID etc

Connection Camera type

Control ID 1

Camera IP Address 192.168. 6. 56

Camera type PTZ


IP Video Encoder


IP cameras connected to a NVR have an additional camera IP address field.


Advanced setup of Inputs


Add/ remove inputs:

An input represents a physical device input or an input on a DVR/ NVR.





Use the  button to add a new location/ site to the configuration of inputs.




Use the  button to add a new input to the location/ site.





Use the  button to remove a input from a location/ site.



Use the  button to remove a location/ site and all the inputs within it.

A [connection](#) must be assigned to the input, and the input must belong to a location/ site



Use the  button to expand the collection tree view or the  button to collapse the collection tree view.



Select the connection from the tree view by right-click on the item

Location/ site Type:

Default site number is 1, and default size is 1024.

If EasyView is connected to SystemX the site number uniquely identifies the site, and the devices on the site.

The site size is used when EasyView is connected to SystemX, and the total number of sites must be increased, and thus the number of devices per sites must be decreased.



The screenshot shows a software interface with two tabs: 'Connection' and 'Camera type'. The 'Connection' tab is active. Below the tabs, there are two input fields. The first is labeled 'Site' and contains a spinner box with the number '1'. The second is labeled 'Site size' and contains a dropdown menu with '1024' selected.

Input type:

The input type have different attributes, such as control ID, input pin, source type and input type.

Connections | Input config

Control ID

Source

Input type

Input ID

The valid source types are:

- λ Input/Output for digital input devices
- λ Camera for IP cameras, video encoders and NVR's
- λ DVR, for DVR's


The valid input types are:


- λ Normal, for standard digital inputs
- λ MotionDetection, for motion detection events


Advanced setup of Outputs


Add/ remove outputs:

An output represents a physical device output or an output on a DVR/ NVR.




Use the  button to add a new location/ site to the configuration of outputs.




Use the  button to add a new output to the location/ site.





Use the  button to remove a output from a location/ site.



Use the  button to remove a location/ site and all the outputs within it.

A [connection](#) must be assigned to the output, and the output must belong to a location/ site



Use the  button to expand the collection tree view or the  button to collapse the collection tree view.



Select the connection from the tree view by right-click on the item

Location/ site Type:

Default site number is 1, and default size is 1024.

If EasyView is connected to SystemX the site number uniquely identifies the site, and the devices on the site.


The site size is used when EasyView is connected to SystemX, and the total number of sites must be increased, and thus the number of devices per sites must be decreased.



The screenshot shows a software interface with two tabs: 'Connection' and 'Camera type'. The 'Connection' tab is active. Below the tabs, there are two input fields. The first is labeled 'Site' and contains a spinner box with the number '1'. The second is labeled 'Site size' and contains a dropdown menu with '1024' selected.

Output type:

The output type have different attributes, such as control ID, output pin and source type.



The screenshot shows a configuration window with two tabs: 'Connections' and 'Output Config'. The 'Output Config' tab is active. It contains three fields:

- Control ID:** A numeric spinner box with the value '1'.
- Source:** A dropdown menu with 'DVR' selected.
- IO pin:** A numeric spinner box with the value '1'.

The valid source types are:


- λ Input/Output for digital input devices
- λ Camera for IP cameras, video encoders and NVR's
- λ DVR, for DVR's


Advanced setup of Monitors


Add/ remove monitors:


A monitor represents a physical monitor output of a matrix connected via SystemX to EasyView.


The monitor is used on a monitor wall, which is a special map, containing only monitors.



Use the  button to add a new location/ site to the configuration of monitors.



Use the  button to add a new monitor to the location/ site.

Use the  button to remove a monitor from a location/ site.

Use the  button to remove a location/ site and all the monitors within it.

A [connection](#) must be assigned to the monitor, and the monitor must belong to a location/ site



Use the  button to expand the collection tree view or the  button to collapse the collection tree view.



Select the connection from the tree view by right-click on the item

Location/ site Type:

Default site number is 1, and default size is 1024.

If EasyView is connected to SystemX the site number uniquely identifies the site, and the devices on the site.


The site size is used when EasyView is connected to SystemX, and the total number of sites must be increased, and thus the number of devices per sites must be decreased.



The screenshot shows a software interface with two tabs: 'Connection' and 'Camera type'. The 'Connection' tab is active. Below the tabs, there are two input fields. The first is labeled 'Site' and contains a spinner box with the number '1'. The second is labeled 'Site size' and contains a dropdown menu with '1024' selected.

Monitor type:

The monitor type have only one attribute, the control ID.




Connections Monitor config


Monitor ID


Advanced setup of Alarms

An alarm represents a handling of one of the inputs assigned to EasyView.

Add/ remove an alarm:



Use the  button to add a new alarm to be handled.

Use the  button to remove an alarm.

Select input source:

Select the input from the tree view, by right-click on the item. The inputs in the list shown corresponds to the [inputs](#) defined.

If the newest alarm is to be presented on the top of the alarm list, this check box must be checked.

If the priority of the input source is to be used, as in case of SystemX inputs, this check box must be checked, otherwise a priority must be assigned

Assign a handling:



A map view may be assigned to the handling.


The way the handling is cleared must be assigned to be either:

- λ When alarm is still active, that is the input is unchanged
- λ Manually by the operator or user
- λ When the alarm goes off, that is when the input is changed
- λ By timeout

If the views is to be blanked when the alarm is cleared the check box "Dispose cameras" must be checked.

The handling may be disabled by un-checking the "Handling enabled" check box.

Assign an output:




Select the output by right click on an output in the tree view listing the valid [outputs](#).

Configure the output state when alarm is active.

The valid actions for the output are:

- λ Follow the handling of the alarm
- λ Follow the alarm input
- λ Timed

Assign cameras:



Select the split format to be used in the action, that is the number of views to be used.

Select a view.

Select the camera to be shown in the view by right click on the [camera](#) in the tree view.

Select a preset for the camera, provides it is a PTZ camera.

EasyView Mode

EasyView has 3 modes:

Design Mode

In Design Mode, the user configures and adds/removes devices, cameras, users, alarms, maps etc. The configuration is stored in an EasyView configuration file. Design Mode requires administrator rights.

Layout Mode


Layout Mode defines the EasyView windows that shall be present in Operational Mode, and where the EasyView windows shall be located on the monitor screen. The layout may contain EasyView windows like split screens, camera list, map view, alarm list etc. The layout is stored in an EasyView layout file.

Layout Mode defines the layout of the EasyView windows only. Layout Mode does NOT define the EasyView configuration. This is done in Design Mode. Layout Mode requires administrator rights.

Operator mode

In Operational Mode the operator can view live cameras, view recordings etc.

Design Mode



You are now in the Design mode

The name of the present opened EasyView database is written in the title bar.
The following describes the design mode menu system:

File

This menu contains the following submenus:

- λ New
This submenu create a new, empty and nameless EasyView database.
Please immediate give a name to the EasyView database using the SaveAs submenu.
- λ Open
This submenu opens an uses an existing EasyView database file for the present EasyView configuration.
- λ Save
This submenu saves all changes to the currently open EasyView database.
- λ SaveAs
This submenu saves the EasyView database to a new file.
- λ LogOff
This submenu opens the Log Off dialog box with options to Log Off EasyView, Exit EasyView or Cancel.
- λ Exit
This submenu exits from EasyView.

View

This menu contains the following submenus:

- λ Map List
The Map List maintains a list of bitmaps added by the user.
Each bitmap can be used as the current selected Map View having camera, input and output icons etc.
- λ Alarm List
The Alarm List maintains a list of alarm handlings defined by the user.
- λ Monitors
This submonitor handles the Monitor Map having analogue monitor icons defined by the user.
- λ Macro List
The Macro List maintains a list of macro handlings defined by the user.
- λ Advanced Setup
In Advanced Setup the user is able to control devices (connections), cameras, inputs, outputs, monitors and alarm handlings.
This submenu is for the experienced user only.
- λ User log
This submenu handles the user log.

Wizard

This menu contains a number of wizards making it simple for the user to configure EasyView.
It has the following submenus:

- λ Alarm
This submenu activates an Alarm wizard creating an alarm handling based on a defined input.
- λ Map View
This submenu activates a Map View wizard adding a user defined bitmap to the Map List.
- λ Users
This submenu activates a User wizard being able to create, remove and modify EasyView users.
- λ SystemX Import
This submenu activates a SystemX import wizard being able to import SystemX devices, cameras, monitors, inputs and outputs to EasyView.
The import is based on a Node Manager export file.
- λ DVR
This submenu activates a DVR import wizard being able to create, remove and modify DVR devices, cameras, inputs and outputs in EasyView.
- λ InterVIEW Import
This submenu activates an InterVIEW import wizard being able to import InterVIEW devices to EasyView.
- λ NVR Camera Import
This submenu activates a NVR Camera Import wizard being able to create, remove and modify NVR devices and cameras in EasyView.

Layout

This menu has the following submenu:

- λ Show
This submenu leaves the design mode and switches to layout mode.
- λ Layout to use
This submenu attach the layout file with the EasyView database. The attached layout file is shown on the right hand side of the status bar at the bottom.



Tools

This menu has submenus corresponding to the tools added to the \Tools directory under the EasyView application directory.

Help

This menu has the following submenu:

- λ About
Gives the version number of EasyView and other relevant information.
- λ Getting started
Opens the "Getting started" dialog.

Bottom Menu




Click on the  button to open the Log Off dialog box with the following options:

- λ Log Off EasyView
- λ Exit EasyView
- λ Cancel

Click on the  button to leave design mode and to enter operational mode.

Layout mode



You are now in the Layout Mode.

The Layout Mode defines the EasyView windows that shall be present in Operational Mode, and where the EasyView windows shall be located on the screen.

You can add EasyView windows like split screens, camera list, map view, alarm list etc.

The layout is stored in an EasyView layout file.

Note:


**Layout Mode defines the layout of the EasyView windows only.
Layout Mode does NOT define the EasyView configuration. This is done in Design Mode.**

For more information on the three EasyView modes:

- λ Design Mode
- λ Layout Mode
- λ Operational Mode

read the F1-help for the Design Mode.


View menu



To add a window to the EasyView layout, select the window type from the View menu. The following windows are available for the EasyView layout:

- λ Map List
This will add a Map List to the layout.
At maximum one Map List pr. layout is permitted.
- λ Alarm List
This will add an Alarm List to the layout.
At maximum one Alarm List pr. layout is permitted.
- λ Monitors
This will add an analogue Monitor Map to the layout.
At maximum one Monitor Map pr. layout is permitted.
- λ Camera List
This will add a Camera List to the layout.
At maximum one Camera List pr. layout is permitted.
- λ Output List
This will add an Output List to the layout.
At maximum one Output List pr. layout is permitted.
- λ Input List
This will add an Input List to the layout.
At maximum one Input List pr. layout is permitted.
- λ Split Screen
This will add a Split Screen to the layout.
Several Split Screens pr. layout are permitted.
- λ Map View
This will add a Map View to the layout.
At maximum one Map View pr. layout is permitted.
- λ Macro List
This will add a Macro List to the layout.
At maximum one Macro List pr. layout is permitted.
- λ Browser
This will add a browser window to the layout.

Remove a window from the layout


To remove a window from the EasyView layout, click on the  button.

Moving and resizing windows inside layout

Windows can be moved and resized the way you normally operates on Microsoft Windows. The contents of the windows, e.g. the bitmap of a Map View, sometimes causes a big system response time when windows are moved. Therefore it is possible to choice an option making only the borders of the windows visible.

Right-clicking in the middle of a window gives the option to toggle Hide Control items On or Off. This has only effect in Layout Mode.

PopUp windows




By default, a window added in Layout Mode will be visible in Operational Mode. However some of the EasyView windows may be defined as PopUp windows.

In Operational Mode, a PopUp window is invisible until the user right-clicks the top area of the monitor screen. This will display the list of available PopUp windows that can be opened by the user.

In Layout Mode, right-clicking in the middle of a PopUp window gives the following options:


- λ Popup
This is a toggle option. When checked the corresponding window is defined as a PopUp window.
- λ Popup location set
When a PopUp window has been moved to its final place in the layout, select this submenu to save the location, where the PopUp window will show up in Operational Mode.

Windows menu




The Layout menu contains the following submenus:

File menu



- λ New
This submenu create a new, empty EasyView layout.
Please immediate give a name to the EasyView layout using the SaveAs submenu.
- λ Open
This submenu opens and uses an existing EasyView layout file as the present EasyView layout.
- λ Save
This submenu saves all changes to the present open EasyView layout file.
- λ SaveAs
This submenu saves the EasyView layout to a new EasyView layout file.
- λ Exit
This submenu leaves the Layout Mode and returns to Design Mode.
Important:
Leaving Layout Mode, saves a link in the present EasyView configuration file to the EasyView layout file.

Status bar



On the status bar the name of the layout file is shown. Also the coordinates of the window currently selected is shown.


Operational Mode

You are now in Operational Mode. Depending on the configuration, the operator can:


- λ View cameras
- λ View recordings
- λ Handle alarms
- λ Handle inputs/outputs
- λ Handle analogue camera/monitor cross points

Top Menu




Right-click the top area of the screen to activate the top menu. The top menu lists all the windows defined as pop up. Select a window to open it. When finished, click on the  button to close the window.

To the right the current time is shown.



Right-click on the time display to activate the tool menu.




Bottom Menu




Click on the  button to open the Log Off dialog box with the following options:

- λ Log Off EasyView
- λ Exit EasyView
- λ Cancel

Click on the  button to leave operational mode and to enter design mode.

Split Screen

This is the Split Screen help.



An EasyView layout may have several split screens containing views. Each split screen can handle up to 16 digitized live or playback streams.

The first split screen loaded is marked with a key-symbol in layout mode.

The first view in this screen is selected by default at start up. Furthermore this first split screen is selected by the alarm handling.

Optional text may be assigned to each split screen.

Split Screen

This is the Split Screen help.



An EasyView layout may have several split screens containing views. Each split screen can handle up to 16 digitized live or playback streams.


The following defines the operations that can be performed on a split screen.

Split screen formats

From the grey panel on top of the split screen it is possible to select between 1, 4, 1 + 5, 1 + 7, 9 or 16-split format.

If e.g. a 9-split format is selected, the first split screen group consists of the first 9 splits and the second split screen group consists of the remaining 7 splits.

The page menu items is used to select the groups, and the sub menu items below each of these items is used to select the group containing the camera by camera name.

The group navigate keys  are used to select next/ previous group.



Live/Playback split

A split can be used for digitized live or playback video streaming.

When used for live, the split has a dark blue top bar. When used for playback, the split has a green top bar.

Active split

The active split is decorated with a yellow border. Single-click the top bar of a split to make this the active split.

Video streaming in a split

Live or playback video streaming in a split can be made several ways:


- λ Drag/Drop from camera list
Drag a camera from the camera list and drop it in the selected split.
- λ Drag/Drop from map view
Drag a camera from the map view and drop it in the selected split.
- λ Select camera
The active split is used for video streaming.
- λ Alarm handling
An alarm handling may start up to 16 video streams.
- λ Multi action
A multi action may start up to 16 video streams.
- λ Macro

If a macro is running in the split, the macro may sequence between several camera streams.

Starting a video stream in an already streaming split, will cause the split to close its present stream and start the new one.

Single split menus

When a split is used for live viewing or playback, the corresponding streaming menu can be reached in 2 ways:

- λ Press the  button on the top bar.
- λ Right-click the mouse button on the top bar.

The following defines the streaming menu items. What menu items are available depends on the camera device.

Live viewing menu:


- λ Camera Control
The Camera Control takes care of all camera PTZ handling.
- λ Image Configuration
The Image Configuration handles the parameters brightness, contrast, sharpness, hue and saturation.
- λ Stop Stream
This menu stops the stream.
- λ Stream Configuration
The Stream Configuration handles parameters like bit rate, resolution etc.
- λ Playback
This menu converts the live viewing into a playback (if supported by the driver) for the selected camera. The menu has the following two options:
 - γ By time
The playback will start at a time selected by the user.
 - γ Quick
Depending on the driver, the playback will start 1 minute behind or at the last recording.


Playback menu:

- λ Playback Control
The Playback Control takes care of all playback options like snapshot, video clip etc.
- λ Stop Playback
This menu stops the playback.
- λ Live
This menu converts the playback into live viewing for the selected camera.

Camera Control


If the camera in a split is a PTZ camera, there are 3 ways to make PTZ in a split with a live video stream.


- λ Camera control dialog
As described above it is possible to get a separate camera control dialog via the  button on the top bar.
- λ Split PTZ panels
From the PTZ panels at the bottom of the split, it is possible to make the most common PTZ operations:
Call Preset, Pan Left, Pan Right, Pan Up, Pan Down, Zoom In and Zoom Out.

The  button is used to change between the panels.
- λ PTZ in split
The camera will move based on where in the split (video stream) the mouse button is pressed.
Pressing left in the split, the camera will move left etc.
Some camera types may not support this functionality.

Playback Control

Having a playback in a split, there are 2 ways to make control it:

- λ Playback control dialog
As described above it is possible to get a separate playback control dialog via the  button on the top bar.
- λ Split playback panels
From the playback panels at the bottom of the split, it is possible to make the most common playback operations:
Change time, Pause/Play, Single step forward/backward (in pause mode) and Fast forward/backward (in play mode).

The  button is used to change between the panels.
The recording time line displays the available recordings (if supported) for the selected day.
Right-click the mouse button on the time line to switch between a 24-hour line and a 1-hour line.

To change the playback time, click and hold the mouse button in the recording area.
While moving the mouse button to the left or right, the time slider will display the actual new time.
When satisfied, release the button at the selected new time.


Split screen menu


Right-click the mouse button on the grey top bar of the split screen to get the split screen menu. The split screen menu applies to all video streams.

- λ Stop All Streams
Stops the all video streams in the split screen.
- λ All Live
Converts all playbacks into live video streams.
- λ All Playback
Converts all live video streams into playbacks (if supported by the driver).
 - γ Time adjust
The playbacks will start at a time selected by the user.
 - γ Quick
Depending on the driver, the playbacks will start 1 minute behind or at the last recording.
- λ Set time on all playback streams
Synchronize all playbacks to a time defined by the user.

Split Maximize/Normalize

The following describes the ways to maximize and normalize the whole split screen:

Press the  button to maximize the whole split screen to full screen size. The present selected split format is not affected.

Press the  button to return the whole split screen back to its original size and position. Double-clicking the grey top bar of the split screen will have same Maximize/Normalize effect as with the magnifier symbols.

The following describes the way to maximize and normalize a single split:
 Double-click the top bar of a single split to maximize this split to full screen size.
 Regardless of previous settings, the split format will be changed to 1-split format.
 Double-click the top bar of the single split once again to return to the previous screen size, position and format.

Wizards

EasyView has wizards to easy the most common setup.

The wizards include:

[Alarm](#)

This wizard is used to creating an alarm handling based on a defined input.

[Map View](#)

This wizard is used to create a map view.

[Users](#)

This wizard is used to add/ remove/ modify EasyView users.

[SystemX Import](#)

This wizard is used to import a System-X database file.

[DVR](#)

This wizard is used to create sites, and to add/ remove/ modify DVR's.

[InterVIEW Import](#)

This wizard is used to import an InterVIEW database.


[NVR](#)

This wizard is used to add/ remove NVR servers, and to import cameras from the NVR servers.

User setup

The [user setup wizard](#) is used to configure the valid users and their rights when using EasyView.


User Setup



This is the User Setup dialog. This dialog adds and removes EasyView users.

Add New User




Press the  button to add a new EasyView user with default parameters. Information on

- λ Name
The name of the EasyView user (login name).
- λ Password
The password for the user name (login password).
- λ Priority
The priority used in all actions or operations made this user. The smaller number the higher priority.
- λ User rights
There are to kinds of EasyView users:
 - γ Standard
The standard user can use functions in operational mode only.
 - γ Administrator
The administrator has complete access to all functions in EasyView in design mode, layout mode and operational mode.
- λ User Access group
The user must be assigned to a user right group to have access to the functions in operational mode.

Remove User

Select/Single-click on the EasyView user (e.g. in the Name field).



Press the  button to remove the corresponding EasyView user from the list.


User Access Group



Press the  button to enter the user access group setup.

Name	Live View	Camera PTZ	Playback	Outputs	Monitors	Alarms
All	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
No Access	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Add New User Access group

Press the  button to add a new EasyView user access group with default no access rights.

Check the functions to be granted access for, using the left-click of the mouse.


Remove User Access group

Select/Single-click on the EasyView user access group (e.g. in the Name field).

Press the  button to remove the corresponding EasyView user access group from the list.

User Access Granted

The status bar at the bottom show the granted access rights of the current user, when the Finish button has been pressed.



System-X Wizard

The System-X wizard is used to import a System-X configuration file.

The wizard includes:

[Import](#)

Import of the configuration file exported from the NodeManager.


[COM Port](#)

Assignment of the COM port to be used for the RS-232 connection to LonWorks.

[Database file](#)

The database file to be created or modified with the System-X import.

System-X Import File Wizard page



This is the System-X Import File Wizard dialog. This dialog imports a System-X configuration to EasyView.

Import file

The System-X import to EasyView is based on a System-X export file generated by the Node Manager. Click on the [Browse](#) button to search for the Node Manager System-X export file. This file normally has the extension [.mdb.SysX.Txt](#).


Keep previous system X devices

Checking this box keeps the System-X devices already configured in the EasyView database. Unchecking it removes all already configured System-X devices before importing the new ones.

Site size

The site size must be selected. The options are: 512 and 1024 (default).

System-X Import PCIF Wizard page




This is the System-X Import PCIF Wizard dialog. This dialog imports System-X PCIF devices to EasyView. The list shows the available devices.

PCIF Import

Each System-X PCIF device has the following parameters:

- λ I151SX-PCIF Name
The name of the PCIF device. This field is read-only.
- λ COM port
The serial COM port on the EasyView PC where the PCIF device is connected.
The COM port can be selected from drop-down list reflecting the available PC COM ports.
- λ Enable
Select Yes to import the corresponding PCIF device. Select No not to import it.

System-X Save File Wizard page



This is the System-X Save File Wizard dialog, saving the System-X configuration to an EasyView database. Click on the [Browse](#) button to search for or create a new EasyView database. An EasyView database has the extension [.evc](#). Click on the [Finish](#) button to save the database and to close the wizard.

Map View Wizard

The map view wizard has the following steps:

[Background image](#)


The background image used for the map view.

[Name](#)

The name of the map view.

[Items](#)

The items to be shown on the map view, and the actions assigned to the items. [Mapview Wizard page](#)



This is the Map View Setup dialog.


Image File

Click on the Browse button to search for a bitmap to be used as Map View. Available formats are: BMP and JPG.

Preview

The preview window shows the selected bitmap.

Mapview Name Wizard page



This is the Map View Setup dialog.

Map Name

The name for the bitmap will be displayed in the Map List.

Mapview Items page



This is the Map View dialog.

On the Map View it is possible to place icons representing the EasyView configuration: Fixed cameras, PTZ cameras, Outputs, Inputs, Alarm handlings, Multications and Navigations.

Add icon

An icon is added to the Map View by dragging it from the icon list at the bottom and dropping it at the desired place on the Map View.

Delete icon

Deleting an icon is done the standard Microsoft way selecting the icon and pressing the Delete keyboard button.

Resize icon

Resizing an icon is done the standard Microsoft way to resize Microsoft windows.

Overlapping icons

See the section on [Icon menu](#) below.

Configure icon

Double-click the icon to open the property dialog and to configure the icon.

Icon type

There are several types of icons that can be placed on the Map View. The same icon type can be used more than once.



This icon represents a fixed camera that can be used for live camera viewing.



This icon represents a PTZ camera that can be used for live camera viewing.



This icon reflects the On/Off status of a device output.



This icon represents the On/Off status of a device input.



This icon reflects the On/Off status of an alarm handling.



This icon represents a multiaction. A multiaction defines a number of performed actions. These actions can be:

- λ View a number of cameras in the split screen

- λ Set a number of outputs
- λ Change map view
- λ Play a sound
- λ Set a number of crosspoints between analogue cameras and analogue monitors




This icon represents a navigation link to another Map View.

Image

Click the [Image](#) button to replace the present bitmap with another one. The Map View name and all defined, configured icons will remain unchanged.

Icon menu



It is possible to do certain actions on an icon by selecting it and Right-click the mouse button on the icon. This will bring up a menu. The following defines this menu:

- λ Send To Back
This will send the icon to the back meaning that it will be hidden behind other overlapping icons.
- λ Bring To Front
This will send the icon to the front meaning that it will be visible upon other overlapping icons.
- λ Default size
This will reset the size of the icon to 50x50 px.
- λ Properties
This will open the property dialog equal to a double-click on the icon.
- λ Delete
This will delete the icon equal to pressing the [Delete](#) keyboard button.
- λ Copy
This will copy the icon and its contents for a later [Paste](#) operation.

Paste



If a previous [Copy](#) has been on an icon, it is possible to paste it. Click on the Map View somewhere and Right-click the mouse button. Select the [Paste](#) submenu. This will paste the icon the selected place. Not all icons can be Copy-Pasted.

Alarm Wizard

This Alarm Wizard is used to setup actions on alarm inputs.

The configuration steps for each alarm input include:

[Alarm source](#)

The input which trigger the action.

[Cameras](#)

The cameras to be shown as video streams in a split view.

[Cross points](#)

The monitors to be used and the camera shown on each monitor.

[Outputs](#)

The outputs to be activated.

[Map view](#)

The map view to be shown.

[Clearance](#)

The way the alarm is cleared.

Alarm Source Wizard page

Alarm setup

Alarm source
Please specify alarm source and alarm priority

Alarm text: Door entrance

Alarm source: EDNS4000 Input 1

Define priority

Alarm priority: []

< Back Next > Cancel

This is the Alarm Source Wizard page.

Alarm text

The name of the alarm.


Alarm source

This defines the input source that will cause the alarm handling to start when the input becomes active. Click on the Source button to open and select an input from the input list.

Alarm priority

Check the Define priority box to select a user defined priority for the alarm. Priority 1 is highest. If the box is unchecked the priority from the input is used. Not all input types have a priority included. Alarms with the highest priority will be served first.

Multi Action Camera Wizard



This is the Multi Action Camera Wizard page.
This page adds and removes digitized cameras shown for the multi action.

Split view format

Click on the split screen icons to the left to select the format.
It is possible to select between None, 1-split, 4-split, 9-split and 16-split. The split view list will reflect the chosen format.


Camera

Select/Single-click on the split view to be changed.
Press the Camera button to open and select a digitized camera from the camera list.
If the camera is a PTZ camera a preset call can be made too. Preset "0" or "--" means no preset.

Clear

Select/Single-click on the split view to be changed.
Press the Clear button to remove the camera from the selected split view.

Alarm Cross Point Wizard page



This is the Alarm Cross Point Wizard page.
This page adds and removes cross points between analogue cameras and analogue monitors to be executed for the alarm handling.

Add

Click on the Add button to add a new empty cross point to the cross point list.

Remove

Select/Single-click on the cross point entry (e.g. the Monitor field) to be removed.
Press the Remove button to remove the corresponding cross point entry from the list.

Monitor

Select/Single-click on the monitor field that shall be changed.
Press the Monitor button to open and select an analogue monitor from the monitor list.

Camera

Select/Single-click on the camera field that shall be changed.
Press the Camera button to open and select an analogue camera from the camera list.
If the camera is a PTZ camera a preset call can be made too. Preset=0 means no preset.

Alarm Output Wizard page

This is the Alarm Output Wizard page.
This page adds and removes outputs to be set for the alarm handling.

Add

Click on the Add button to add a new empty output to the output list.

Remove

Select/Single-click on an output in the list.
Press the Remove button to remove the corresponding output from the list.

Pin


Select/Single-click on an output in the list.
Press the Pin button to open and select an output from the output list.

Options

Select/Single-click on an output in the list. The following options for the output can be selected:

- λ None
When selected, the output remains On even after the alarm has been cleared.
- λ Follow AlarmHandling
When selected, the output goes Off when the alarm is cleared.
- λ Timed
When selected, the output goes Off after a number of defined seconds.

Alarm Map View Wizard page



This is the Alarm Map View Wizard page.
This page changes Map View and plays a sound during the alarm handling.


Map View

During the alarm handling, a new bitmap from the Map List may be selected as the Map View. Select it from the drop-down list. A preview of the bitmap can be seen in the panel.


Sound

Check the Enable Sound box if a sound should be played during the alarm handling. There are the following options:

- λ General sound
The sound "C:\Ernitec\EasyView\Sounds\Alarm.wav" is played.
- λ Specific sound

Browse for a sound file to be played pressing the  button.
The sound file is automatically copied to the directory "C:\Ernitec\EasyView\Sounds".

Alarm Clearance Wizard page



This is the Alarm Clearance Wizard page.
This page sets certain clearance parameters for the alarm handling.

- λ Allow user to clear alarm
Check this box if the user manually should be allowed to clear the alarm.
If checked, it should be defined whether the alarm can be cleared even if the alarm source is still active.
- λ Follow the state of alarm source
Check this box if the alarm should automatically be cleared when the alarm source is not longer active.
- λ Timeout
Check this box if the alarm should be clear after a number of configurable seconds.
- λ Dispose cameras
Check this box if the defined camera streams should be stopped when the alarm is cleared.

DVR Wizard

The setup a DVR includes:

Site

The site or location on which the DVR are placed.

DVR configuration

The configuration of the DVR assigned to the site.

Cameras

The cameras and the properties for the cameras to be used on the DVR.


Inputs

The inputs to be used on the DVR.

Outputs

The outputs to be used on the DVR.

DVR Site Wizard page



This is the DVR Site Wizard dialog.

This dialog adds or removes sites. A site groups a number of cameras, input and outputs.


Add

Press the Add button to add a new location named "Site" to the Site List.
The name of a site can be changed by normal text edit.

Remove


Select/Single-click on the site that shall be removed.

Press the **Remove** button to remove the corresponding site from the Site List.



Press the **View config** button to show the current DVR configuration tree. The configuration tree is read-only.

DVR Unit Wizard page



This is the DVR Unit Wizard dialog. This dialog adds and removes DVR units.

Select Site

Before doing any Add or Remove, the site must be selected from the drop-down site list.

Add

Press the **Add** button to add a new DVR unit with default parameters. Information on

- λ DVR name
Normal text field.
- λ DVR address
Either the ip address or host name may be used.
- λ User name
The user name shall reflect one of the user names configured in the DVR.
- λ User password

The password for the user name.

λ DVR type


There are 2 possible options: DigiOp DVR or EDNS2000.

must be given.

Remove


Select/Single-click on the DVR unit (e.g. the DVR name) that shall be removed.
Press the **Remove** button to remove the corresponding DVR unit from the DVR unit List.

View config



Press the **View config** button to show the current DVR configuration tree.
The configuration tree is read-only.

DVR Camera Wizard page



This is the DVR Camera Wizard dialog. This dialog adds and removes DVR cameras.

Select DVR

First the actual DVR unit must be selected from the DVR unit list.
Only the DVR units on the previous selected site are shown.

Add

Press the **Add** button to add a new DVR camera with default parameters.

Information on


- λ Camera Name
Normal text field.
- λ Camera ID
The Camera ID is the video input number on the DVR to which the camera is connected.
- λ Camera type
There are 2 possible options: FIX or PTZ.

must be given.

Remove


Select/Single-click on the DVR camera (e.g. the Camera Name) that shall be removed.
Press the **Remove** button to remove the corresponding DVR camera from the DVR camera List.

View config



Press the **View config** button to show the current DVR configuration tree.
The configuration tree is read-only.

DVR Input Wizard page



This is the DVR Input Wizard dialog. This dialog adds and removes DVR inputs.

Select DVR

First the actual DVR unit must be selected from the DVR unit list.
Only the DVR units on the previous selected site are shown.

Add

Press the Add button to add a new DVR input with default parameters.
Information on


- λ Input Name
Normal text field.
- λ Input ID
The Input ID is the digital input number on the DVR.

must be given.

Remove


Select/Single-click on the DVR input (e.g. the Input Name) that shall be removed.
Press the Remove button to remove the corresponding DVR input from the DVR input List.

View config



Press the View config button to show the current DVR configuration tree.
The configuration tree is read-only.

DVR Output Wizard page



This is the DVR Output Wizard dialog. This dialog adds and removes DVR outputs.

Select DVR

First the actual DVR unit must be selected from the DVR unit list.
Only the DVR units on the previous selected site are shown.

Add

Press the Add button to add a new DVR output with default parameters.
Information on


- λ Output Name
Normal text field.
- λ Output ID
The Output ID is the digital output number on the DVR.

must be given.

Remove

Select/Single-click on the DVR output (e.g. the Output Name) that shall be removed.
Press the Remove button to remove the corresponding DVR output from the DVR output List.

View config



Press the View config button to show the current DVR configuration tree.
The configuration tree is read-only.

NVR Wizard

The NVR wizard includes:


Server

Assignment of the NVR server.

Cameras

Import of the cameras assigned in the NVR server.

NVR Server Wizard page



This is the NVR Server Wizard dialog. This dialog adds and removes NVR servers.

Add

Press the Add button to add a new NVR server with default parameters.
Information on

- λ Name
The name of the NVR server.
- λ Server type
There are 2 possible options: IP EasyView NVR Basic or IP EasyView NVR Standard.
- λ Address
Either the ip address or host name may be used.
- λ User name
The user name and the password define the access to the NVR server.
- λ Password
The password for the user name.

must be given.


Remove

Select/Single-click on the NVR server (e.g. in the Name field) that shall be removed.
Press the Remove button to remove the corresponding NVR server from the NVR server List.

Import from server

This field defines the NVR server from which a camera import should take place.
The NVR server is selected from the drop-down list holding the defined NVR servers.

NVR Camera Wizard page



This is the NVR Camera Wizard dialog. This dialog selects and configures NVR cameras.

Select

Select the NVR cameras that shall be imported, clicking the check box at each camera. The Select all button selects all NVR cameras and the Select none button unselect all NVR cameras.

Configuration

The NVR camera list holds the cameras defined in the selected NVR server. Each camera has the following information:

- λ Camera Name
The name of the NVR camera. This field is read-only.
- λ IP address
The IP address of the NVR camera. This field is read-only.
- λ Password
The password for the user name. This field is read-only.
- λ User name
The user name and the password define the access to the NVR server. This field is read-only.
- λ Type
The type of the NVR camera (FIX or PTZ) must be selected. If the option PTZ is selected, the ID field can be changed too.
- λ ID
The Camera ID used for PTZ control. If the selected NVR server is of type Ernitec NVR, the ID is the Camera ID set physically on the PTZ camera. In most cases the Camera ID=1. If the selected NVR server is of type TBD NVR, the ID is the camera number inside the NVR server. In this case the ID should not normally be changed.
- λ Location
The location under which the NVR camera shall be placed, must be selected.
- λ Video Encoder
This field specifies whether the NVR camera is a Video Encoder or not. This field is read-only.

Locations

This opens a dialog where locations can be added or removed. Click the Add button to add a new location. Click the Remove button to remove a location.

Map View List

The [map view list](#) shows the map views defined.

Map View List



This is the Map List dialog.

The Map List maintains a list of bitmaps added by the user.

On each bitmap the user can add icons representing cameras, inputs, outputs, monitors, alarm handlings etc.

The present used/selected bitmap in Operational Mode is called the Map View.

The following defines the possible actions:

Add

Click on the Add button to open the Map View wizard and to add a new bitmap to the Map List.

Remove

Single-click on/select a bitmap from the Map List.

Click on the Remove button to remove the bitmap from the Map List.

Default Map View

To configure a bitmap as the default startup Map View in Operational Mode,

Single-click on/select the bitmap from the Map List,

and check the Use as Startup map

Map View design

Double-click on a bitmap to open it as a Map View.

When opened, icons representing cameras, inputs, outputs, monitors etc. can be added to the bitmap.

Macro


A macro defines a number of cameras to be shown in a split view, for a period of time.

The macro is defined in the [macro list view](#).

At runtime a macro may be started in the split view selected, using the [runtime macro list view](#).

Macro

Macro List



This is the Macro List dialog.

The Macro List maintains a list of macros defined by the user.

Each macro contains a sequence of actions as described in the section [Macro Action Wizard](#).

The Macro List defines the following actions:

Add

Click on the Add button to add a new, empty macro with a predefined name at the end of the Macro List.

Remove

Single-click on/select a macro in the Macro List.
Click on the Remove button to remove the macro from the Macro List.

Edit

Single-click on/select a macro in the Macro List.
Click on the Edit button to open the Macro action dialog and edit the macro sequences.
It is also possible to open the Macro action dialog by double-clicking a specific macro.

Macro Action Wizard

This is the Macro Action Wizard. This dialog handles the macro sequences in a specific macro.

Name

Enter a name for the macro.

Add Camera

This button adds a "Show Camera" sequence to the end of the Macro Sequence List.
The camera is selected from the present camera list and a preposition can be called (if the camera is a PTZ camera)

Add Delay

This button adds a "Delay" sequence to the end of the Macro Sequence List.
The delay is defined as a number of seconds.

Add Pin

This button adds a "Set output pin" sequence to the end of the Macro Sequence List.
The output pin is selected from the present output list
and it must be set to go On or Off.

Refresh

This button refreshes the Macro Sequence List.

Remove

Single-click on/select a sequence in the Macro Sequence List.
Click on the Remove button to remove the sequence from the Macro Sequence List.

Edit

Single-click on/select a sequence in the Macro Sequence List.
Click on the Edit button to edit the Camera, Delay or Pin sequence.
It is also possible to edit the sequence by double-clicking it.

Macro repeated

If checked, the macro will start all over with the first macro sequence
after having performed the last sequence in the Macro Sequence List.
If not checked, the macro will stop after having performed the last sequence in the Macro Sequence List.

Macro



This is the Macro Operational dialog used to Start or Stop macros.

Start macro

Single-click on/select a split window where to execute the macro.

The selected split window is marked with a yellow border.

Single-click on/select a macro and click the Start/Stop button.

The macro should start executing in the split window and the state should change to Running.

Stop macro

Single-click on/select a running macro and click the Start/Stop button.

The macro should stop executing and the state should change to Stopped.

Alarm view

The alarm view has three pages:

Present alarms

The current alarms in the alarm handling.

Current log

The alarms in the current log file.

Alarm log

The alarms in a selected log file.

Alarm List

Alarm Text	Priority	Location	Time	Clearance	Show
EDNS4000_I1	2	DigiOp	2008/01/17 11:59:55		<input type="button" value="Live"/> <input type="button" value="Recorded"/>

Clear Test

Alarm list | Alarm log | Alarm log file

This is the Alarm List. It contains all active alarms.

All alarms in the list are prioritized having the alarm with the highest priority listed first.

A new alarm will be placed in the list according to its priority. If the new alarm becomes the first alarm in the list, it will be executed. When an alarm is cleared, it is removed from this list and moved to the Alarm Log. If the cleared alarm was the first alarm in the list, the next alarm in the list will be executed.

An alarm in the list contains the following information:

- λ Alarm Text
The name of the alarm

- λ Priority
The priority of the alarm. The smaller number the higher priority.
- λ Location
The location of the alarm source
- λ Time
The time when the alarm became active.
- λ Clearance
Not used by the alarm list.
- λ Live
Always has the text "Live".
- λ Recorded
Always has the text "Recorded".

Clear

Select/Single-click on an alarm in the list. Press the **Clear** button to manually clear the alarm.

This is only possible if the Allow user to clear alarm box has been checked in the alarm configuration.

Alarm handle test

If defined by the alarm source driver, it is possible to simulate or test an alarm handling.

Select an alarm handling from the drop list and press the **Test** button.

Alarm Log

File					
Alarm Text	Priority	Location	Time	Clearance	Show
EDNS4000_I1	1	DigiOp	2008/01/17 11:59:55	?	<div style="border: 1px solid black; padding: 2px;"> <div style="background-color: #e0e0e0; padding: 2px;">Live</div> <div style="padding: 2px;">Recorded</div> </div>

Alarm list Alarm log Alarm log file

This is the Alarm Log.

The Alarm Log contains all alarms that have been cleared since the start of EasyView operational mode.

An alarm in the log contains the following information:

- λ Alarm Text
The name of the alarm
- λ Priority
The priority of the alarm. The smaller number the higher priority.
- λ Location
The location of the alarm source
- λ Time
The start time when the alarm became active and the end time when the alarm was cleared.
- λ Clearance
Defines how the alarm was cleared. The options are:
 - γ User
The alarm was cleared manually by the user.
 - γ Input
The alarm was cleared because of the alarm source (input) going Off.
 - γ Timed
The alarm was cleared due to a timeout
- λ Live
Always has the text "Live".
- λ Recorded
Always has the text "Recorded".

File

Use the menu items **Save** or **Save As** to save the present alarm log in a log file.

If the log file should be visible for EasyView, the log file must be placed in the directory "C:\Ernitec\EasyView\Logs\Alarms\".

Alternate menu


Select/Single-click on an alarm in the list.

Right-click the alarm to get access to the alternate menu containing the following options:

- λ Live
Start a live stream for the cameras included in the alarm handling for the alarm.
- λ Recorded
Start a playback (if available) for the cameras included in the alarm handling for the alarm.
The playbacks start at the time where the alarm was activated.

Alarm Log Archive

This is the Alarm Log Archive used to view saved alarm logs.



Use the file menu item Open to open the alarm log file dialog.
All alarm logs for a given day is displayed in the list as the activation time for the first alarm in the log file.
Select an activation time and press the **OK** button to open the corresponding log file.
Alarm log files must be placed under the directory "C:\Ernitec\EasyView\Logs\Alarms\" to be visible for the dialog.

Alternatively the user can press the Browse button to search for a specific alarm log file anywhere in the file system.

Alarm Text	Priority	Location	Time	Clearance	Show
c:\Ernitec\EasyView\Logs\Alarms\ALog20080103_120237.alg - 03/01/2008 12:02:37 - 03/01/2008 12:16:08					
EDNS4000_I1	1	DigiOp	2008/01/03 12:14:16 - ...	Input	
EDNS4000_I1	1	DigiOp	2008/01/03 12:14:23 - ...	Input	

Alarm list Alarm log Alarm log file

An alarm in the log contains the following information:

- λ Alarm Text
The name of the alarm
- λ Priority
The priority of the alarm. The smaller number the higher priority.
- λ Location
The location of the alarm source

- λ Time
The start time when the alarm became active and the end time when the alarm was cleared.
- λ Clearance
Defines how the alarm was cleared. The options are:
 - γ User
The alarm was cleared manually by the user.
 - γ Input
The alarm was cleared because of the alarm source (input) going Off.
 - γ Timed
The alarm was cleared due to a timeout
- λ Live
Always has the text "Live".
- λ Recorded
Always has the text "Recorded".

Alternate menu

Select/Single-click on an alarm in the list.

Right-click the alarm to get access to the alternate menu containing the following options:

- λ Live
Start a live stream for the cameras included in the alarm handling for the alarm.
- λ Recorded
Start a playback (if available) for the cameras included in the alarm handling for the alarm.
The playbacks start at the time where the alarm was activated.