

How to get a Password Reset For Cameras & NVR's

1. Download MicroView IP Tool
2. Select Camera or NVR
3. Export Password File
4. Save the Password File
5. Send the file to Ernitec
6. Import the reset file from Ernitec



1. Download MicroView IP Tool & Install it.

Go to Ernitec.com under products choose MicroView By Ernitec, choose any camera and click on it . Click on the software button and the IP Tool will download automatic.

MicroView
by ernitec




MVID-03IR-E

- Up to 2 Megapixel Full HD
- 1/2.7" Progressive scan CMOS
- Dual Stream
- 2.7 - 12mm Varifocal Motor lens
- Digital Wide Dynamic Range
- 3D Digital Noise Reduction
- DC12V & PoE
- Support H.264+
- IP67 Weather-Proof Protection
- IK10 Impact Protection
- Upto 30m IR range
- Built-in Micro SD card slot
- 3-axis adjustment
- 3 year Warranty

- Data Sheet PDF
- Quick Guide
- Manual
- Software


2. Select Camera or NVR

Connect your camera to your PC with a switch and launch the IP tool and you will see all active cameras and NVR's..




3. Export Password File

Press Export to export the password file to your PC



4. Save the Password File

Follow the guides on the picture and you will select the folder where to save the file..



5. Send the file to Ernitec

Send an E-mail to support@ernitec.com and request a password reset remember to write the model number and attach the password file, when you get it back use same procedure to import the new file into the camera or NVR. Then you can enter a new password ...