



SYSTEM X

M32SYNX


Installation Instruction - Installierungsanleitung - Notice d'installation - Instrucciones para su Instalación

1


x 16




2







x 3



3



4



HEAD OFFICE: ERNITEC A/S, HØRKÆR 24, DK-2730 HERLEV, DENMARK
 TELEPHONE: +45 44 50 33 00, TELEFAX: +45 44 50 33 33
 HOMEPAGE: www.ernitec.com, E-MAIL: ernitec@ernitec.dk

UK OFFICE: ERNITEC UK, GERRARD HOUSE, WORTHING ROAD, EAST PRESTON, WEST SUSSEX, BN16 1AW
 TELEPHONE: 01903 77 27 27, TELEFAX: 01903 77 27 07
 E-MAIL: sally@ernitec-uk.co.uk

GERMAN OFFICE: ERNITEC GmbH., STORMARNRING 28, 22145 STAPELFELD
 TELEPHONE: (040) 67 56 25 0, TELEFAX: (040) 67 56 25 25
 E-MAIL: ernitec@aol.com

FRENCH OFFICE: ERNITEC FRANCE, N° 29 PARC CLUB DU MILLENAIRE, 1025 RUE HENRI BECQUEREL, 34036 MONTPELLIER CEDEX 1
 TELEPHONE: 04 67 15 10 15, TELEFAX: 04 67 64 01 81
 E-MAIL: ernitec@ernitec.fr

MIDDLE EAST OFFICE: ERNITEC ME, HAMRA-MAKDESI STR., YOUNIS CENTER-5th FLOOR, OFFICE NO. 503
 P.O. BOX 113/5721, BEIRUT, LEBANON
 TELEPHONE: +961 1 751 796, TELEFAX: +961 1 751 795
 HOMEPAGE: www.ernitecme.com, E-MAIL: malek_kabrit@ernitecme.com

2853-00005

