

Ernitec EVR 5.xx series

Network port settings

SMTP prot	25
Web browser port	80
POP3 e-mail notification port	110
RMC and SDK port	5001
SM server port	5008
DVR server port	5009
Watchdog server port	5010
Streaming server port	5011
Gateway Server Port	9000
HTTP server port	9999
Hardware e-mail notification port	54321

All port settings are TCP/IP

Remark:

DVRServer never contacts the applications or SMServer. However, if IP cameras are installed in the system, DVRServer contacts the IP cameras using TCP or UDP (TCP port 80) depending on the camera model.

For more information see EVR installation guide